

Connection of Weight Indicator E2075



J2 9p D-sub Load Cell contact(cable mounted)

1. + Signal green
2. - Signal yellow
- 3.
4. + Sense pink
5. + Excitation brown
- 6.
- 7.
8. - Sense gray
9. - Excitation white

The shield is connected to the hood of the Dsub.

9p D-sub RS232 interface contact

- 1.
2. TXD
3. RXD
- 4.
5. GND
- 6.
- 7.
- 8.
- 9.

For some more information of the contacts, please see page 6 and 8 in B02490 Instruction Manual for E2075 3000 Series.

J5 Screw terminal for Load Cell (inside the indicator box)

1. +EXCITATION brown
2. +SENSE pink
3. +SIGNAL green
4. GND shield
5. -SIGNAL yellow
6. -SENSE gray
7. -EXCITATION white

Note!

The colour-code is Unisystem's standard, but it can differ.